



Elevation Reference Point and Swing Ties

Elevation Reference Point





Input into Elevation Reference Point (ERP) Window is also printed to HHE-200 Page 3

<p>ELEVATION REFERENCE POINT Location & Description: 29" dia. White Pine Nail 55" high Reference Elevation is 0.0' or _____</p>

Note: If the ERP was not located by swing ties then leave all distances blank. A label will be printed to page 2 and 3 maps.

Horizontal Reference Point



Note: If the HRP was not located by swing ties then leave all distances blank OR press CANCEL button.