


SeptiCAD Cross Section Notes - Customize

Access via SeptiCAD Preferences 

List of All System Types

Directions for inserting a Block Note

Note for each System



System Type	Note or Block for System
Enviro-Septic/GEO-Flow Pipe	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF B
BioDiffuser Hi-Capacity	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
BioDiffuser Bio 2	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
Quick4 Hi-Capacity	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
Quick4 EQ 24	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
Type-B Eljen In-Drain	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
Reverse Type-B Eljen In-Drain	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
Stone Bed	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O
4' x 8' Concrete Chamber (Cluste	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. BED THICKNESS FROM BASE OF STONE TO TO
8' x 4' Concrete Chamber (Cluste	\NNOTE: SCARIFY ALL GROUND SURFACE TO BE FILLED. USE GRAVELLY COARSE SAND WITHIN 3' OF O

Edit Note

Note to Edit -->

Edited Note -->

Save Changes

Discard Changes

Edit Cross Section Note (See Note #1)

NOTE:

- (1) To edit a Note, click on a Note, then click on the Edit Note button. Make the changes to the Note (may want to do this in a text editor). When editing is complete, click Make Changes button. To format the text, such as underline, bold or special characters use the special character codes for mText objects.